



Super Jet Dishwasher Detergent

Item #: 1772

PROBLEM : While family dinners around the table are wonderful, there's usually a load of plates, glasses and utensils—not to mention dirty pots and pans—for the dishwasher after the meal. And doing a dishwasher-load every day or two can have an impact on your family's health, the environment and even your pocketbook.

SOLUTION : Super Jet Dishwasher Detergent not only gets your dishes their cleanest, even in hard water, it's also safe for the environment and easy on the family budget.



Description:

Super Jet Dishwasher Detergent conditions and softens water and minimizes hard-water and lime buildup. It thoroughly cleans up to 25 loads of dishes, glassware, cutlery, plasticware, pots and pans, or up to 40 loads when used with the Magnet Ball. It's even more economical compared to most other detergents because you use only a tablespoon for each full load of dishes. And it's phosphate-free, fragrance-free and chlorine-free so it can't harm the environment or impact waterways.

500 g / 17.6 oz.

Key Features:

- Biodegradable
- Non-toxic to aquatic organisms
- Fragrance-free
- Phosphate-free
- Chlorine-free
- Safe for septic systems
- No animal testing
- Container is recyclable, HDPE #2.

Key Benefits:

- Gets dishes their cleanest, even in hard water.
- Washes and rinses china and glassware, leaving them clean and sparkling
- Helps minimize water spotting
- Conditions and softens water
- Removes sticky, greasy residue
- Minimizes hard water and lime buildup
- Gentle on the environment
- Won't pollute local waterways
- Saves money since you use less

How to Use:

- Remove large food particles from dishes and rinse. Place dishes and utensils in dishwasher, being sure that soiled surfaces face water spray. Place one tablespoon (15 ml) of Super Jet Dishwasher Detergent directly in dispenser. Not for use in dishwashers with stainless steel lining.
- Not recommended for hand dishwashing.

Note: If dishes come out spotty, you may be using too much dishwasher detergent. You may need to use only one-half to one teaspoon if you have a Magnet Ball.

Separate stainless steel flatware from sterling silver. Do not spill onto silver items. Detergent may cause dark spots (removable with silver polish).

Did You Know?

- For best results, load large items along the sides and back of the dishwasher so they don't block the water and detergent. Face the dirtier side of dishes toward the center of the machine, and don't let dishes or utensils nest. Place items with baked-on food in the bottom rack, face-down toward the sprayer. Rest glasses upside down on prongs so they don't fill with water. Use the top rack for plastic and delicate items that are dishwasher-safe. www.consumerreports.org/cro/dishwasher-detergents/buying-guide.htm

COMPLEMENTARY PRODUCTS

- Dishwashing Liquid
- Magnet Ball

